

UNV-35809

Owner's Manual

8 Digit Display Calculator

FEATURES

Large, 8-Digit Display – big, easy-to-read LCD numbers.

Four Function Memory – includes addition, subtraction, recall, and clear.

Dual Solar/Battery Power – built-in solar panel extends battery life by powering the calculator in the light.

Automatic Power Off – saves battery power by turning off the calculator if it is left unused for about 7 min.

OPERATING THE CALCULATOR

ON/C Key - Power ON / Clear LCD / Clear Entry. Power OFF after a few minutes if no button is pressed. If a result is too big to show in the LCD, the calculator stops and displays E. Press ON/C to continue.

+/- Key - Press to change the displayed number from positive (+) to negative (-) or from negative (-) to positive (+).MINUS - is displayed when the value is negative.

PERFORMING CALCULATIONS

Addition (+) *Example:* 6 + 7 = 13 Press [6] [+] [7] [=] *13*

Subtraction (-) Example: 10 - 4 = 6 Press [1] [0] [-] [4] [=] 6

Multiplication (x) *Example:* 7 x 5 = 35 Press [7] [x] [5] [=] *35*

Division (÷) Example: $14 \div 7 = 2$ Press [1] [4] [÷] [7] [=] 2

MEMORY FUNCTIONS

[M+] Press to add the displayed number to memory. MEMORY is displayed.

[M-] Press to subtract the currently displayed number from memory.

[MRC] Press once to display the number stored in the memory and twice to reset the memory to 0.

Percentages (%)

Calculate 6% of 200.

Press [2] [0] [0] [x] [6] [%]

Add 6% tax to a \$20 purchase.

Press [2] [0] [+] [6] [%] 21.2

12

Calculate 20% discount from \$150.

Press [1] [5] [0] [x] [2] [0] [%] 30

REPLACING THE BATTERY

- 1. Remove the two screws on the rear panel. Using a flat edge, pry open the rear panel.
- 2. Slide out the old battery. Insert the new battery with the + side up.
- 3. Replace the rear panel.

CARE AND MAINTENANCE

- Keep the calculator dry. If it gets wet, dry it before use.
- Do not use harsh solvents or detergents to clean the unit.
- Do not drop or strike the calculator.